



*their safety is essential.*

Products made to work hard—and built to last.

## EcoPolyBlend™ Spill Control Pallets

Keep workers safe from accidental slips indoors and avoid costly hazardous material cleanup costs

Leakproof EcoPolyBlend™ Spill Control Pallets are EPA compliant to protect against ground contamination and help you avoid potential fines. Ideal for drum filling and dispensing operations. Choose from in-line or square configurations, with or without drain.

- Seamless construction eliminates leaks
- Durable polyethylene construction is chemical resistant
- Self-locating grates stay firmly in place, yet are removable for easy cleaning
- Forklift pockets make relocating easy
- Nestable design minimizes storage space requirements when not in use
- Black models and grates made with 100% recycled polyethylene
- Black color hides grime and dirt to keep your workplace looking clean
- Yellow models are high-visibility, easy to see on job sites
- EPA compliant and supports SPCC



Use pallet as a workstation for waste collection.



28623



28626



28631



Optional ramp for 4-drum square models makes loading and unloading heavy drums easy.



Description	Sump Capacity Gallons/Liters	Load-bearing* Capacity lb/kg	External Dim. W x D x H	Compliance†	Model No Black	Model No Yellow	Ship Wt lb/kg
2 drum in-line pallet	66/250	2500/1134	49 x 25 x 18 in / 1245 x 635 x 457 mm	E, S, O, I	28623	28622	44/20
2 drum in-line pallet w/drain					28625	28624	
3 drum in-line pallet	75/284	3750/1701	73 x 25 x 11.625 in / 1854 x 635 x 295 mm		28627	28626	58/26
3 drum in-line pallet w/drain					28629	28628	
4 drum in-line pallet	75/284	5000/2268	97 x 25 x 9 in / 2464 x 635 x 229 mm		28631	28630	77/35
4 drum in-line pallet w/drain					28633	28632	
4 drum square pallet	73/276	5000/2268	49 x 49 x 10.25 in / 1245 x 1245 x 260 mm		28635	28634	70/32
4 drum square pallet w/drain					28637	28636	
Ramp for 28635	—	1000/454	49 x 33 x 10.50 in / 1245 x 838 x 267 mm	—	28688	28620	40/18

### EcoPolyBlend™ Replacement Grates (100% recycled)

2 drum grate for all sizes above	24 x 48 x 2.5 in / 610 x 1219 x 63 mm	—	28259	—	16/7
1 drum grate for 3 drum in-line	24 x 24 x 2.5 in / 610 x 610 x 63 mm		28260		8/4

\*Loads are stated as a total safe allowable uniform distributed load and apply to service temperature range of -30°F to 120°F (-34°C to 49°C)

†E = EPA compliant; S = supports SPCC; O = OSHA compliant; I = IFC compliant

(800) 798-9250 • Justrite.com