

2 Quart Steel Plunger Dispensing Can, Perforated Pan Screen Serves as Flame Arrester, Yellow - 10218

Product Images



Short Description

- Moisten cleaning cloths quickly and easily
- Design leaves less liquid in bottom before having to refill
- Perforated upper pan serves as flame arrester
- Top rim features molded edge protector

Description

Dispense flammable liquids and solvents safely, without waste or exposure. Made of chemically resistant Ryton® and brass, the pump base is designed to leave less liquid in the bottom before having to refill.

Pushing down on the pump assembly fills the upper pan with liquid. Surplus liquid drains safely back into reservoir. The perforated upper pan serves as a flame arrester. Top rim has molded edge protector for smooth, trouble-free moistening.

Specifications

Model No	10218
UPC	697841002890
International Model No.	10218
FM Approval	Yes
TUV Approval	Yes
Color	Yellow
Material Specifications	Steel
Dimensions, Exterior	7.375" H x 7.25" Outer Dia.
Dimensions, Exterior	187mm H x 184mm Outer Dia.
Capacity	2 quarts
Dasher (Inch)	5
Dasher, mm	127
Net Weight, lbs	2.2
Net Weight, kg	1.0