

2 Quart Steel Bench Can, with Perforated Dasher Plate, Red - 10295

Product Images



Short Description

- Easily clean small parts in solvent
- Spring loaded, perforated dasher plate
- Hinged cover minimizes evaporation losses

Description

Simply place work on spring-loaded, perforated dasher plate, press down and agitate, then release to return dasher to drain position. Plated steel dasher also works as an effective flame arrester to reduce the risk of fire flashback. Hinged cover minimizes evaporation losses and protected rim reduces the possibility of hand injury. Cans are made of sturdy 24-gauge steel with tough powder-coat finish.

Specifications

| | |
|-------------------------|-----------------------------|
| Model No | 10295 |
| UPC | 697841002920 |
| International Model No. | 10295 |
| Pallet Quantity | 70 |
| FM Approval | Yes |
| TUV Approval | Yes |
| Color | Red |
| Material Specifications | Steel |
| Dimensions, Exterior | 3.25" H x 9.375" Outer Dia. |
| Dimensions, Exterior | 83mm H x 238mm Outer Dia. |
| Capacity | 2 quarts |
| Liter Capacity | 2 |
| Dasher (Inch) | 7.5 |
| Dasher, mm | 191 |
| Net Weight, lbs | 3.8 |
| Net Weight, kg | 1.7 |