

# 1 Gallon Steel Bench Can, with Perforated Dasher Plate, Parts Basket, Red - 10370

## Product Images



## Short Description

- High quality 1 gal (4 L) steel bench can to easily clean small parts and wet large cloths
- Can dimensions of 4.5 in H x 9.35 in OD (11.4 cm H x 23.8 cm OD)
- Spring-loaded, perforated dasher plate serves as a flame arrester
- Hinged cover minimizes solvent evaporation losses
- Available in red
- FM Approved & TUV Certified
- Comes with parts basket for cleaning small parts

## Description

---

Use this reliable and durable 1 gal (4 L) 24-gauge steel bench can (model 10370) with a tough powder-coat finish to dip and rinse small parts or wet large cleaning cloths with combustible liquid solvents.

This bench can has an exterior height of 4.5 in (11.4 cm) and an outer diameter of 9.375 in (23.8 cm), and weighs 4.5 lb (2.0 kg). The accompanying dasher plate is 7.5 in (19.1 cm). Model 10370 is red and is FM Approved and TUV Certified.

Bench cans make cleaning operations even easier. To use, place items on the spring-loaded, perforated dasher plate. Press down to agitate, then release to return the dasher to the drain position (above liquid level), where excess liquid drains off safely. The dasher tray covers the opening of the wide, shallow can.

## Cleaning Small Parts Is Simple & Safe With a Bench Can

Many industries require safely cleaning small parts and wetting large cloths. Some of these include manufacturing, maintenance, repair, construction and lab sites within the steel, automotive, airline, agriculture, food, paper, and chemical industries.

For safety purposes, the combustible liquid in the can is below the tray level. The plated steel dasher works as an effective flame arrester screen to reduce the risk of fire flashback. There is a hinged cover to minimize evaporation losses, while the protected rim reduces the possibility of hand injury.

This model comes with a parts basket ([model 11171](#)) that fits into the dasher tray and provides extra convenience when immersing small parts.

## Specifications

---

Model No	10370
UPC	697841003125
Brand	Justrite
International Model No.	10370
Pallet Quantity	108
FM Approval	Yes
TUV Approval	Yes
Color	Red
Material Specifications	Steel
Dimensions, Exterior	4.5" H x 9.375" Outer Dia.
Dimensions, Exterior	114mm H x 238mm Outer Dia.
Capacity	1 gallon
Liter Capacity	4
Dasher (Inch)	7.5
Dasher, mm	191
Net Weight, lbs	4.5
Net Weight, kg	2.0