

## 2 Gallon Dip Tank for Cleaning Parts, Manual Cover With Fusible Link, Steel, Red - 27602

### Product Images



## Short Description

---

- Portable, safe solution to parts cleaning
- Cover stays open for convenient access
- Self-closing in case of fire

## Description

---

Use for cleaning parts and subassemblies where the volume of work does not warrant a larger rinse tank. Portable size accommodates changing production requirements. Dip tank covers stay open for convenient access; self-closing mechanism and fusible link melts at 165°F (74°C) to snap the cover shut in case of fire.

## Specifications

---

Model No	27602
UPC	697841010598
Brand	Justrite
International Model No.	27602
Pallet Quantity	72
FM Approval	Yes
TUV Approval	Yes
Color	Red
Material Specifications	Steel
Dimensions, Exterior	10" H x 9.375" Outer Dia.
Dimensions, Exterior	254mm H x 238mm Outer Dia.
Capacity	2 gallon
Liter Capacity	8
Net Weight, lbs	4.3
Net Weight, kg	2.0

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).