
Antistatic Wire For Bonding/Grounding, With "C" Clamp 5/8 inch and Alligator Clip 5/8 inch, 3 feet.

Product Images



Short Description

Key Benefits

- Reduce fire risks by preventing sparks from static electricity
- Flexible wire

Description

Use antistatic wires to prevent sparks from static electricity generated by movement and flow of flammable liquids. During waste collection operations, use one antistatic wire to bond from a safety container to a receiving vessel such as a funnel, then properly ground by attaching a second antistatic wire to the drum and then to an earth ground. Standard wire lengths are 3-foot (1-M) and 10-foot (3-M); for longer reach, use

several wires with ¼-in (6-mm) terminal ends. Custom length assemblies are available in 3-foot (1-M) increments.

Specifications

Model No	08501
UPC	697841001831
International Model No.	08501
Color	Silver
Material Specifications	Flexible Wire
Net Weight, lbs	0.5
Net Weight, kg	0.2
End Connection 1	"C" Clamp
End Connection 2	Alligator Clip