

## Brass Drum Gate Valve for Viscous Liquids, 2" NPT bung - 08552

### Product Images

---



## Short Description

---

- Ideal for viscous liquids
- Safe and easy dispensing from horizontal drums
- 2-inch NPT (DN50)
- FM Approved

## Description

---

Simply place these faucets on your drum for leakproof dispensing of flammable liquids. Faucets feature an internal flame arrester that prevents flashback of fire into the drum for added safety. Brass construction with a polytetrafluoroethylene (PTFE) seal ensures excellent chemical resistance. Take the worry out of awkward spout position with adjustable models 08910 and 08916. They feature a coupling nut that provides rotation of the spout downward after the faucet is threaded in place. Use Model 08552 for viscous noncorrosive flammables such as adhesives, paint or heavy oils above 2000 SSU (about 30W oil).

Faucets are FM Approved.

## Specifications

---

Model No	08552
UPC	697841001923
Brand	Justrite
International Model No.	08552
Material Specifications	Brass
Dimensions, Exterior	235mm H x 197mm W x 110mm D
FM Approval	Yes
Wetted O-Rings	PTFE
Flame Arrestor Material	Brass
Cover Type / Closure Type	Self Close
NPS/NPT inch	2
NPS/NPT mm	51
Net Weight, lbs	6.6
Net Weight, kg	3.0

## Prop 65

---

**WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).