

5 Gallon Steel Drain Can, Plated Steel Funnel, Yellow - 10906

Product Images



Short Description

- Easy collection of used solvents
- Wide-mouth funnel catches drainage
- Built-in flame arrester

Description

Easily and safely collect used solvents from parts washing equipment with a Justrite drain can. Wide-mouth funnel catches drainage with no spill, no mess. Removable funnel is plated steel. Built-in flame arrester keeps fire from contents. A 3/4" threaded plug allows safe disposal of waste liquids from the drain can into a permanent receptacle. Optional drain can cover fits on top of funnel to keep out dirt.

Specifications

| | |
|-------------------------|-------------------------------|
| Model No | 10906 |
| UPC | 697841004122 |
| Brand | Justrite |
| International Model No. | 10906 |
| FM Approval | Yes |
| Color | Yellow |
| Material Specifications | Steel |
| Dimensions, Exterior | 16.75" H x 11.625" Outer Dia. |
| Dimensions, Exterior | 425mm H x 295mm Outer Dia. |
| Capacity | 5 gallon |
| Liter Capacity | 19 |
| Net Weight, lbs | 7.0 |
| Net Weight, kg | 3.2 |