

Countertop Oily Waste Can accepts small wipes and swabs, 2 gallon.

Product Images



Short Description

- Ideal for collecting wipes, cotton swabs, or small brushes soaked with solvents, adhesives, or thinners.
- Prevent fires caused by stray sparks or spontaneous combustion
- Lid stays closed when not in use
- Small hand-operated size ideal for use on top of workbenches and counters
- Approved by FM Approvals

Description

OSHA compliant Oily Waste Cans are essential when using solvent soaked cloths and wiping rags. Rags and cloths soaked with thinners, linseed oil, combustible adhesives, and other flammable liquids present a serious fire risk when discarded improperly. The specially designed lid opens no more than 60 degrees and stays closed when not in use. This isolates the contents from fire sources and limits oxygen, virtually eliminating a risk of spontaneous combustion. All cans feature a galvanized steel body construction with durable powder-coat finish.

Compact oily waste cans for use on top of workbenches or counters are ideal for collecting wipes, cotton swabs, or small brushes soaked with solvents, adhesives, or thinners. Countertop style is only 9-1/8-in(232mm) tall and easily accepts small wipes.

Specifications

Model No	09200 / 09200Y
FM Approval	Yes
OSHA Compliance	Yes
Material Specifications	Steel
Dimensions, Exterior	9.125" H x 9.625" Outer Dia. 232mm H x 244mm Outer Dia.
Capacity	2 gallon
Liter Capacity	8
Net Weight, lbs	5.3
Net Weight, kg	2.4

Product Options

Color:	Red
	Yellow