

# Steel Gas Cylinder Support Bracket With Chain, Two 12" Cylinder Capacity, Wall Mount - 35268

## Product Images



## Short Description

- Brackets accept cylinder sizes ranging from 4- to 12-in (102- to 305-mm)
- Exclusive bumper guard edging with steel reinforced vinyl protects your cylinders from damage while providing extra grip
- Includes secondary support chain for an improved level of safety on any installation
- Designed for wall mounting applications

## Description

Cylinder support brackets provide a quick and easy solution for storing gas cylinders when space is at

premium. Constructed from heavy gauge, powder-coated steel to ensure long service life and chemical resistance. Heavy-duty polypropylene support straps, 1.5- x 54-in (38-mm x 1372-mm) and rated at 1138-lb (516-kg), feature steel cinch buckle and hold individual cylinders securely against bracket. Welded and plated, heavy-duty size 2/0 steel chains with twist link allows links to lay flat against the cylinders, enabling a tighter fit and preventing damage to required labeling.

Helps comply with OSHA, NFP1, NFPA 55, and CGA.

## Specifications

Model No	35268
UPC	697841210905
Cylinder Capacity	2
Minimum Cylinder Diam (in)	4
Cylinder Capacity with Max Cylinder Dia	(2) 12 inch
Mount Type	Wall
Mount Holes	4
Mount Hole Size (inch)	0.406
Strap Style	Poly Cinch Strap with Steel Buckle and Chain
Straps Per Cylinder	1
Material Specifications	Steel
Complies with NFPA 1 Fire-Code	Yes
NFPA 55	Yes
OSHA Compliance	Yes
CGA	Yes
Net Weight, lbs	9
Net Weight, kg	4
Net Dimensions (W x D x H)	23.75 x 2.25 x 4.25 inches
	603 x 57 x 108 mm