

Safety Snap Cap for Gas Cylinders, Low Pressure-Fine Thread - 35360

Product Images



Short Description

- Limit unauthorized access to valve control—includes brass padlock
- Fits low pressure, fine thread cylinders—3.5-in x 11UN threads
- Meets ISO 11117, DOT 49 CFR, CSA B340, and CGA V-9

Description

Reduce potential accidents and theft of costly cylinder contents. Designed to fit most North American gas cylinders, the Safety Snap Cap restricts access to the main cylinder control and regulator attachment, providing a lockout device that prevents unauthorized use. Simply mount cap to cylinder and attach regulator, close cap and attach padlock. Design allows access to the valve handle without having to remove the cap and replace the regulator each time cylinder is needed. Welded steel construction and powder coated finish provides many years of use.

Specifications

Model No	35360
UPC	697841211261
Material Specifications	Steel
Complies with NFPA 1 Fire-Code	Yes
NFPA 55	Yes
OSHA Compliance	Yes
D.O.T Approval	Yes
Net Weight, lbs	4
Net Weight, kg	2
Net Dimensions (W x D x H)	5 x 4 x 7.5 inches
	127 x 102 x 191 mm