

Pedestal Mount, Open Stainless Steel Bowl, Hughes Eye/Face Wash, Galvanized Pipe - 85GP

Product Images



Short Description

HUGHES



Justrite Safety Group

- Twin spray nozzles protected by dust covers that pop-off when eye wash is activated
- Diffusers provide a gentle flow of aerated water and prevent further injury to the eyes
- High-performance 316L SS quarter-turn ball valves endure the harshest environments and site conditions
- Includes a separate universal eyewash sign for enhanced visibility,
- Meets ANSI and EN 15154 standards and supports OSHA requirements

Description

Pedestal-mounted, open stainless steel bowl eye/face wash unit, designed at ANSI-compliant height, is generally located in open areas away from walls. Suitable for use in all applications not subject to the possibility of freezing or overheating. The system features a specially designed valve that includes an integral, heavy-duty stainless steel stop-plate to handle rough operation without failure. Low operating torque offers reliable, easy on/off operation. Solid construction using galvanized mild steel pipework. Easy activation, a highly visible red push plate with universal hand and eye wash sign. Includes an inspection record tag for recording service and test history. Add optional foot treadle for a secondary means of activation. Some assembly may be required.

Specifications

Model No	85GP
UPC	805042000052
Net Weight, lbs	22
Net Weight, kg	10
Dimensions, Exterior	45.5" H x 12.4" W x 21.2" D
	1156mm H x 314mm W x 314mm D
UL Classified to ANSI Z358.1-2014	Yes
Water Inlet Size NPT	1-1/4 in (F)
Minimum Operating Pressure	2 bar g, 29 PSI
Maximum Operating Pressure	6 bar g, 87 PSI
Water Flow Eye/Face Liters/min	11.4
Water Flow Eye/Face US Gal/min	3
Material Specifications	Eye/facewash diffusers: Chrome plated brass with stainless steel mesh.
Operating Valve Material	316L Stainless
Eye/Face Wash Bowl Material	Stainless Steel
Mounting Type	Pedestal
Pipework Material	Galvanized Steel
Activation Method	Push Plate
Eye/Face Wash Bowl Interior Dimensions	10.25" W x 10.25" D
	260mm W x 260mm D
Minimum Ambient Temperature, °F	41
Minimum Ambient Temperature, °C	5
Maximum Ambient Temperature, °F	95
Maximum Ambient Temperature, °C	35

Prop 65

⚠️WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.