

DynaLoc Type 3 Day Box Explosive Storage Magazine, Red - EL510

Product Images



Short Description

- For the safe, short-term transport of explosive materials
- For use with explosives, detonators, fireworks, flash bangs, or K-9 Training Aids
- Meets and exceeds ATF 27 CFR, Part 555 requirements
- Durable 12-gauge steel construction lined with 1/2 inch of plywood
- Resistant to fire, weather, and unauthorized access

Description

The Justrite DynaLoc Type 3 Day Box Explosive Storage Magazine, Red – model EL510, is engineered to address the critical needs of safely transporting and storing explosive materials. The EL510 offers a blend of robust construction and user-centric features designed to meet and exceed ATF 27 CFR, Part 555

requirements.

Constructed from 12 gauge steel and hand-welded for structural integrity, it offers protection against fire, weather, and unauthorized access. The interior is lined with 1/2" non-sparking plywood, designed to reduce the risk of accidental ignition, supporting a safer storage environment. For convenience in operation, the design includes fold-away side handles and a top-opening lid for efficient loading and unloading. For added security, it features a durable locking hasp, with welded hinges and hasps that prevent tampering when the magazine is locked.

The exterior and interior surfaces are protected with a high-performance coating system, comprising a modified phenolic alkyd resin base coat and an acrylic alkyd enamel topcoat. This finish ensures chemical resistance inside and offers protection against abrasion, corrosion, and UV damage externally.

Built for the Job Site

Justrite day boxes are lightweight and portable, yet robust enough to withstand daily transport from overnight storage areas to work sites or training facilities. Resistant to fire, weather, and theft, these units ensure explosives are stored under the safest conditions possible.

Applications

The DynaLoc Type 3 Day Box is the ideal solution for a wide range of applications, including:

- Military and law enforcement explosive and ammunition transport
- K-9 training unit material transport
- Municipal explosive and ammunition logistics
- Contractor explosive transport

Specifications

Model No	EL510
UPC	850066616000
Brand	Justrite
Color	Red
Pallet Quantity	8
ATF Compliance	ATF 27CFR, Part 555
Storage Type	Horizontal
Number of Doors	1
Dimensions, Exterior	14.75"W x 11.5"D x 8.13"H
Dimensions, Interior	8.8"W x 12.8"D x 6.75"H
Height (Inches)	8.13
Width (Inches)	14.75
Depth	11.5
Net Weight, lbs	28