

Wall-Mount Flammable Safety Cabinet

Product Images



Short Description

- Space-Saving Design: Maximizes storage without using floor space, positioning on the wall for easy access
- Durable Construction: Built with sturdy 18-gauge double-wall, welded steel and 1.5 inches of insulating air space for superior fire resistance
- Spill Management: Features SpillSlope galvanized steel shelves directing spills to a leakproof 2-inch sump for safety and compliance
- Secure Closure: Includes high-performance, manual-close, self-latching doors with a U-Loc™ handle and optional padlock compatibility

- Compliance and Warranty: Meets OSHA and NFPA standards, FM-approved, with a ten-year warranty for reliability
- Configurability: Available in two capacities (17 or 20 gallons) to meet specific storage needs

Description

Eagle Wall Mounted Safety Cabinets offer a practical solution for maximizing storage space without compromising floor area. By hanging these cabinets above workspaces, you can position them at eye level for easy access to solvents and other flammable liquids. This design ensures that valuable floor space remains available for other uses.

These cabinets are constructed with sturdy 18-gauge double-wall, welded steel and feature 1.5 inches of insulating air space for superior fire resistance. They include high-performance, manual-close, self-latching doors that provide maximum protection under fire conditions. The U-Loc™ handle offers additional security with a cylinder lock and key set or optional padlock compatibility. Haz-Alert™ reflective warning labels enhance visibility in low-light conditions.

The patented SpillSlope® galvanized steel shelves direct spills to a leakproof 2-inch sump, ensuring compliance with EPA requirements. Dual vents with flame arresters and a grounding connector further enhance safety features. The durable lead-free epoxy/polyester powder-coat finish provides excellent chemical resistance and minimizes corrosion effects. These cabinets are available in a bright yellow color, which clearly identifies them as flammable storage units.

Eagle wall mounted safety cabinets are available in 24 gallon capacities. To configure your cabinet, select from yellow, gray or neutral colors and specific door closure type. All cabinets come complete with mounting hardware for easy installation.

Eagle Wall Mounted Safety Cabinets are FM-approved and carry a ten-year warranty, ensuring compliance with OSHA and NFPA standards. By choosing the right cabinet for your needs, you can ensure a safe and compliant storage solution that optimizes your workspace while protecting workers and reducing fire risks.

Specifications

Model No	1900WM
----------	--------

Prop 65

⚠️WARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Product Options

Color:	Yellow
	Gray
	Beige
Door Style:	Self-close
	Manual Close