

# Flammable Horizontal Drum Cabinet

## Product Images





## Short Description

---

- **Sturdy Construction:** Welded, 18-gauge steel with double-wall construction and 1.5 inches of insulating air space provides excellent fire resistance
- **Dispensing Capability:** Designed for use in gravity-flow dispensing applications, with space for a drip-can and tracks to guide the drum cradle
- **Enhanced Safety:** Dual vents with flame arresters and built-in grounding connectors provide additional safety features
- **Spill Containment:** 2-inch leakproof sump captures spills, ensuring safety and compliance
- **Secure Closure:** Three-point stainless steel bullet latching system ensures positive door closure and maximum protection under fire conditions
- **Compliance and Warranty:** FM-approved and meets OSHA and NFPA standards, backed by a ten-year warranty for peace of mind and reliable performance

## Description

---

Eagle horizontal drum safety cabinets are designed for safe storage and use as dispensing stations, accommodating horizontally positioned drums for gravity-flow dispensing applications. The interior includes space for a drip-can and tracks to guide the drum cradle into position. Constructed from sturdy 18-gauge welded steel with double-wall construction and 1.5 inches of insulating air space, these cabinets provide excellent fire resistance. They comply with OSHA and NFPA regulations and are independently fire tested and

approved by FM Approvals.

To configure your safety cabinet, select from the available door closure options: manual closing or self-closing doors. Self-closing doors offer enhanced safety by automatically latching in emergency situations, minimizing human error and ensuring compliance.

Eagle horizontal drum safety cabinets are designed to meet the complex requirements of handling and storing hazardous materials, providing a reliable solution for industries such as laboratories, manufacturing facilities, and chemical processing plants. These cabinets come with a ten-year warranty, providing peace of mind and reliable performance.

## Specifications

---

Model No	DRH
----------	-----

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## Product Options

---

Color:	Red
	Yellow
	Gray
	Beige
	White
Door Style:	Self-close
	Manual Close