

# Deep Space Saver Flammable Cabinet

## Product Images



## Short Description

---

- **Compact Design:** Ideal for limited floor space, providing 48 gallons of additional capacity
- **Durable Construction:** Built with welded, 18-gauge steel double-walls and 1.5 inches of insulating air space for superior fire resistance
- **Spill Management:** Features SpillSlope galvanized steel shelves directing spills to a 2-inch leakproof sump for safety and compliance
- **Secure Closure:** Includes a three-point self-latching door system, available in manual closing or self-closing options
- **Compliance and Warranty:** Meets NFPA and OSHA regulations, FM-approved, with a ten-year warranty for reliability

## Description

---

Eagle Deep Space Saver Safety Cabinets are designed to provide safe storage for flammable and combustible liquids in environments where floor space is limited. These cabinets feature a compact design of 48 gallons, measuring 65 inches in height and 23.25 inches in width, making them ideal for placement alongside larger safety cabinets or in areas such as labs, R&D rooms, garages, and machine shops.

Constructed with welded, 18-gauge steel double-walls and 1.5 inches of insulating air space, these cabinets offer superior fire resistance and compliance with NFPA and OSHA regulations. They include a three-point self-latching door system, a 2-inch leakproof sump, and dual vents with integral flame arresters. The built-in grounding connector ensures proper grounding to reduce static buildup. The cabinets feature galvanized steel shelves that direct spills to the back and bottom of the sump, meeting EPA requirements. Highly reflective Haz-Alert warning labels provide visibility under fire conditions or during power outages.

Deep Space Saver Safety Cabinet are available in yellow or gray, and with manual or self-closing doors. Self-closing doors are a critical safety feature, offering enhanced protection against fires and accidental releases. These doors automatically close and latch in the event of a fire or emergency, using fusible links that melt at 165°F (74°C), causing the doors to shut automatically. This feature minimizes human error by ensuring that the cabinet is always properly closed, even when staff are distracted or forgetful. While manual closing doors are available, self-closing doors provide the safest option, especially in environments where safety is paramount.

Eagle Deep Space Saver Safety Cabinets are FM-approved and carry a ten-year warranty, ensuring peace of mind and reliable performance. By configuring your cabinet, you ensure a safe and compliant storage solution tailored to your unique needs.

## Specifications

---

Model No	DSS
----------	-----

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## Product Options

---

Color:	Yellow
	Gray
Door Style:	Self-close
	Manual Close