

# Pesticide Safety Cabinet

## Product Images





## Short Description

---

- Improve safety and convenience and reduce the risk of accidental poisoning and fires
- Fit almost anywhere and provide protection where space is limited
- Ideal when storing lesser quantities of pesticides
- Allow segregation of liquids stored at worksite
- Meet OSHA and NFPA 30
- FM-approved

## Description

---

Pesticides present a substantial danger to people and the environment when improperly stored. Pesticide safety cabinets allow segregation of liquids stored at the worksite, eliminating the potential for drips and spills during the transfer of pesticides. Dissimilar pesticides stored separately prevent one from contaminating another or the accidental use of the wrong chemical.

Safety cabinets that are specifically designed to house these types of chemicals offer features including sturdy double-wall, 18-gauge steel construction with 1½" of air space and dual flame-arresting vents.

The three-point automatic latch with keyed lock prevents unauthorized access. Steel shelves fitted with corrosion-resistant polyethylene trays adjust on 3" (77mm) centers to accommodate a wide variety of containers.

Manual-close door(s) opens to a full 180 degrees and self-latches when pushed closed. Self-close door(s) shuts and latches automatically when a fusible link melts at 165°F (74°C) under fire conditions. Unique, concealed self-closing mechanism offers obstruction-free access to contents.

All door styles meet OSHA and NFPA 30; self-close door styles also meet NFPA 1 and the International Fire Code.

All cabinets are FM approved and come with a ten-year warranty. Pesticide safety cabinets are available in 60-, 45-, 30-, 24- and 12-gallon capacities.

For indoor maintenance areas in these environments:

- Golf courses
- Park districts
- Amusement parks
- Nurseries
- School campuses
- Lawn care companies
- Farms
- Cemeteries
- Pest control companies

## Specifications

---

Model No	PESTSTD
----------	---------

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## Product Options

---

Capacity:	12 gallon
	24 gallon
	30 gallon
	45 gallon
	60 gallon
Door Style:	Self-close
	Manual Close