

# Paint Safety Cabinet

## Product Images







## Short Description

- Specifically designed for Class III combustibles like paints, inks, and aerosols
- Extra adjustable SpillSlope® shelves maximize storage for paint and other containers
- Durable 18-gauge double-wall welded steel with 1.5-inch insulating air space
- Available in red or yellow for easy identification and segregation of combustibles
- High-performance self-latching doors with U-Loc handle for added security
- FM-approved and meets OSHA and NFPA standards with a ten-year warranty

## Description

---

Eagle Paint Safety Cabinets are specifically designed to safely store and organize Class III combustibles, such as paints, inks, and aerosols, making them ideal for printing, painting, furniture, and motor vehicle operations. Unlike standard flammable cabinets, these cabinets include additional adjustable galvanized steel shelves, providing ample storage for smaller containers while directing spills to a leakproof sump for added safety. Available in red, yellow, white, gray or neutral, these cabinets allow for easy identification and segregation of combustibles in your workspace, and come in capacities of 40 to 96 gallons.

Constructed from durable 18-gauge double-wall welded steel with 1.5 inches of insulating air space, Eagle Paint Safety Cabinets offer superior fire resistance. High-performance self-latching doors ensure secure closure under fire conditions, while the U-Loc™ handle includes a cylinder lock and key set or accepts an optional padlock for enhanced security. Haz-Alert™ reflective warning labels improve visibility during power outages or emergencies. The durable lead-free epoxy/polyester powder-coat finish provides excellent chemical resistance inside and out.

Designed to meet OSHA and NFPA 30 standards, these cabinets are available with manual-close doors that open to a full 180 degrees or self-close doors that automatically latch when a fusible link melts at 165°F (74°C). Self-closing models also comply with NFPA 1 and the International Fire Code. Additional features include dual vents with flame arresters, four adjustable self-leveling feet, a grounding connector, and trilingual warning labels.

Tower paint cabinets with legs feature 4-inch adjustable legs, allowing them to be placed over floor or wall ventilation, which is beneficial in environments where moisture or airflow is a concern. The added height also makes it easy to clean or sweep under the cabinets, and they can be easily moved with a forklift or pallet jack.

Eagle Paint Safety Cabinets are FM-approved and backed by a ten-year warranty, ensuring reliable performance and peace of mind. Whether you need to store paints, aerosols, or other combustible materials, these cabinets provide a safe, compliant, and organized solution tailored to your needs.

## Specifications

---

Model No	PISTD
----------	-------

## Prop 65

---

**⚠️WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

---

Color:	Red
	Yellow
	Gray
	Beige
	White
Capacity:	40 gallon
	60 gallon
	96 gallon
Door Style:	Self-close
	Manual Close
	Bi-Fold

## Product Options