

Space Saver Flammable Cabinet

Product Images







Short Description

- Countertop Convenience: Provides easy access to frequently used liquids while maintaining safety and compliance on workstations and workbenches
- Durable Construction: Built with sturdy 18-gauge steel double-walls and 1.5 inches of insulating air space for superior fire resistance
- Spill Management: Durable shelves directing spills to a leakproof sump for safety and compliance
- Secure Closure: Includes dual vents with flame arresters and available in manual closing or self-closing door options
- Compliance and Warranty: Meets NFPA and OSHA regulations, FM-approved, with a ten-year warranty for reliability
- Versatile Options: Available in four colors (yellow, red, white, neutral/beige) and three capacities (12, 15

& 24 gallons) to meet specific storage needs

Description

Eagle Space Saver Flammable Cabinets offer a versatile and safe way to store flammable liquids and other hazardous materials in a variety of settings, including workstations and workbenches. These cabinets are designed to provide easy access to frequently used liquids while maintaining a high level of safety and compliance with NFPA and OSHA regulations.

Constructed with sturdy 18-gauge steel double-walls and 1.5 inches of insulating air space, these cabinets provide superior fire resistance and durability. They feature shelves that direct spills to a leakproof sump, ensuring safety and compliance. The cabinets also include dual vents with flame arresters, adjustable self-leveling feet, and a built-in grounding connector for added safety.

To configure your safety cabinet, select from various color options, including yellow for flammables, red for combustibles, gray and white for waste storage. Choose from capacities of 12, 15 or 24 gallons to meet your specific storage needs. Additionally, select between manual closing or self-closing doors to ensure compliance with your safety requirements.

Self-closing doors are a critical safety feature in these cabinets, offering enhanced protection against fires and accidental releases. These doors automatically close and latch in the event of a fire or emergency, using fusible links that melt at 165°F (74°C), causing the doors to shut automatically. This feature minimizes human error by ensuring that the cabinet is always properly closed, even when staff are distracted or forgetful. While manual closing doors are available, self-closing doors provide the safest option, especially in environments where safety is paramount.

Eagle Space Saver Cabinets are designed to meet the complex requirements of handling and storing hazardous materials, providing a reliable solution for industries such as laboratories, manufacturing, and chemical processing plants. By configuring your cabinet, you ensure a safe and compliant storage solution tailored to your unique needs.

All Eagle cabinets carry a ten-year warranty and are FM-approved, ensuring peace of mind and reliable performance.

Specifications

Model No	SSCAB
----------	-------

Prop 65

⚠️WARNING: This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Product Options

Color:	Red
	Yellow
	Gray
	Beige
	White
Capacity:	12 gallon
	16 gallon
	24 gallon
Door Style:	Self-close
	Manual Close